

Inclination Mechanism TM-SUA

for BeFREE

1. Turn the BeFREE upside down

2. Open the Inclination Mechanism and place it on the device in such a way that the holes in the mechanism align with the holes of the device, as shown on the image

3. Fix the mechanism with the four supplied screws (Ph M4)

5. To change the angle of the mechanism press the lever at the rear, tilt the display to the desired angle and release the lever to fix the position

4. Press the plastic feet into the openings in the housing

note: you can loosen the 4 screws slightly with BeFREE in standing position, then tighten them again to improve alignment, if necessary.

Only for BF22 and BF20:
The maximum angle can be increased by removing the blocking screw as indicated

