


## Cleaning your Tipro BeFREE Product

1. To prepare for cleaning the touchscreen, power down the BeFREE (if possible) or disable touchscreen with long press on the Home/Touch disable key on the stripe.
2. Do not get liquids inside the unit. BeFREEs are not waterproof! **Do not spray the product directly.**



Instead, use wet wipes, a sprayed cloth or a dampened cloth with the excess moisture squeezed off.



3. Select only non-abrasive cleaning wipes or cloths to avoid scratching touchscreens.
4. Avoid highly concentrated alcohol (> 70%), non-diluted bleach or ammonia solutions, as these may cause discoloration.
5. Wipe the surfaces with the appropriate wipes or cloths and approved cleaning products, and allow them to dry.

## Disinfecting your Tipro BeFREE Product

1. To prepare for disinfecting the touchscreen, power down the BeFREE (if possible) or disable touchscreen with long press on the Home/Touch disable key on the stripe.
2. Dampen a new clean, non-abrasive cloth with a disinfectant chosen from the list below. **Ensure excess liquid is squeezed from the cloth.** You may also use recommended pre-dampened wipes.
3. Read the manufacturer's instructions carefully. Many manufacturers require the surface to remain wet for a few minutes, so continuous wiping might be required.
4. Disinfect the surfaces by wiping them with the cloth or wipe, and allow the surface to dry.
5. For disinfectant solutions that are safe for use with our products, see below.



## List of safe disinfectant solutions safe for disinfecting your Tipro BeFREE Product

- » Household bleach solution (around 1 dl per 2 liters of water)
- » Isopropyl alcohol ( $\leq 70\%$  alcohol)
- » Clorox Disinfecting Wipes
- » Clorox Healthcare Bleach Germicidal Wipes
- » Clorox Commercial Solutions Hydrogen Peroxide Cleaner Disinfectant Wipes
- » Lonza Disinfectant Wipes
- » Lysol Brand Clean & Fresh Multi Surface Cleaner (20% cleaner solution to water ratio)
- » Purell Professional Surface Disinfectant Wipes
- » Sani-Cloth Prime Germicidal Disposable Wipes

## Do NOT use the following materials when cleaning/disinfecting your product

- » Isopropyl Alcohol at concentration  $> 70\%$
- » Methyl Alcohol or Ethyl Alcohol at concentration  $> 35\%$
- » Thinner or benzine
- » Strong alkali lyes
- » Strong solvents
- » Acids
- » Detergents with fluoride
- » Detergents with ammonia at concentration  $> 1.6\%$
- » Abrasive cleaners
- » Detergents with abrasives
- » Formula 409
- » Steel wool
- » Sponges with abrasives
- » Steel blades
- » Cloth with steel threads

For more information regarding cleaning and disinfecting the touchscreen please refer to ELOTouch official site: <https://www.elotouch.de/support/technical-support/cleaning>